

### Basic Steps

1. 3.0m rails can be placed along floor to find centre of holes. Fence post holes can be dug and end posts concreted.
2. String line end posts on the top and back of posts to create a straight fence line and height. Concrete remaining posts ensuring 3.0m gap between post centres.
3. Rails on next followed by picket pales. You can use a string line between posts to guide top of picket pales.
4. Heights of fences can always be adjusted by cutting timbers to preferred lengths. This is a guide to achieve a 1200mm high fence but can be adapted accordingly.

A picket pale should be used to cover the butt joint of two rails

Fence bays should start and continue at 3.0m until your last bay. Only the last bay should be cut down to fit gap. Starting with a smaller bay or trying to equal size of bays will increase required material and will be left short on fence posts and fence rails.

