


How to Measure for Double Gates Using Existing Posts



Firstly decide what height you would like your gates. We recommend allowing a 50mm ground clearance.

Measure the width between your existing posts. In this example it is 3000mm.

Calculation goes like this: $3000\text{mm} - 30\text{mm}$ (hinge and latch tolerances) = 2970mm .

Divide this by 2 to give you the size of each gate leaf = 1485mm wide.

If opening out, hinges must be placed on the face of the posts. If opening inwards, then placed on the back of the posts. The calculation remains the same for either method.

30mm tolerance is what we advise but you can go slightly smaller or bigger. Never go less than 20mm as the gate can swell in wet weather.